SolarTech Power Solutions

Container distribution cabinet installation

12.8V6Ah

Nominal voltage (V):12.8
Nominal capacity (ah):6
Rated energy (WH):76.8
Maximum charging voltage (V):14.6
Maximum charging current (a):6
Floating charge voltage (V):13.6~13.8
Maximum continuous discharge current (a):10
Maximum peak discharge current @10 seconds (a):20
Maximum load power (W):100
Discharge cut-off voltage (V):10.8
Charging temperature (℃):0~+50
Discharge temperature (℃): -20~+60
Working humidity: <95% R.H (non condensing)
Number of cycles (25 ℃, 0.5c, 100%dod): >2000
Cell combination mode: 32700-4s1p
Terminal specification: T2 (6.3mm)
Protection grade: IP65
Overall dimension (mm):90*70*107mm
Reference weight (kg):0.7
Certification: un38.3/msds

Overview

How to install a counter in a cabinet?

2.Firstly, pull the two reference lines in the top of the cabinet and the bottom of the cabinet; Then, put the counter in the order of the drawings, accurately adjust it, then adjust other panels one by one; the disc is consistent, and the arrangement is neat.3. The simulation bus is aligned; the installation is firm.

What is a distribution box?

A distribution box is the heart of any electrical system. It takes the incoming power and safely distributes it to different circuits throughout your building. Whether in a home or an industrial facility, this box keeps your electrical setup organized, functional, and efficient.

How do I choose a distribution box?

First, think about the type of environment. Residential distribution boxes are usually smaller and built for lighter loads. They're great for homes and small offices. On the other hand, industrial boxes are designed for high-capacity use in places like factories, warehouses, or construction sites. Also, decide between indoor and outdoor use.

Container distribution cabinet installation

Contact Us

For catalog requests, pricing, or partnerships, please visit:
https://www.zegrzynek.pl